

## LIGHTING SECTION

### CONTENTS

	<i>Description</i>	<i>Page</i>
<b>Bulb Specifications</b>	.. .. .	H53
<b>Fog and Driving Lamps</b>		
	Detailed parts .. .. .	H3
	Model reference .. .. .	H2
	Supersession chart .. .. .	H52
<b>Headlamps</b>		
	Conversion sets .. .. .	H39
	Detailed parts .. .. .	H5-33
	Lens chart .. .. .	H34
	Model interpretation .. .. .	H4
	Model reference .. .. .	H4
	Motor cycle application .. .. .	H35-38
	Supersession chart .. .. .	H52
<b>Side or Pilot Lamps</b>		
	Detailed parts .. .. .	H41-42
	Lens chart .. .. .	H51
	Model reference .. .. .	H40
	Motor cycle application .. .. .	H40
	Supersession chart .. .. .	H52
<b>Tail, Stop Tail and Number Plate Lamps</b>		
	Detailed parts .. .. .	H44-47
	Lens chart .. .. .	H51
	Model reference .. .. .	H43
	Motor cycle application .. .. .	H48
	Supersession chart .. .. .	H52
<b>Tank Panel Lights</b>		
	Detailed parts .. .. .	H49
	Motor cycle application .. .. .	H49
	Supersession chart .. .. .	H52
<b>Reflex Reflectors</b>		
	Detailed parts .. .. .	H50
	Motor cycle application .. .. .	H50
	Model reference .. .. .	H50
	Supersession chart .. .. .	H52
<b>Warning Lights</b>		
	Detailed parts .. .. .	H49
	Motor cycle application .. .. .	H49
	Supersession chart .. .. .	H52
<b>Supersession Chart</b>	.. .. .	H52